

Take Your  
Time

# Car Lashes™

Enlist a  
Helper

## ATTACHEMENT INSTRUCTIONS (Round Headlight)

### OVERVIEW

- 1: DETERMINE PLACEMENT
- 2: CLEAN SURFACE
- 3: PRACTICE
- 4: ATTACH LASH TO CAR

### DETAILS

***The lash needs to be attached to a clean smooth surface on the vehicle. All of the tape should be touching the surface where the lash is attached. The lash should be rubbed down very firmly—use your thumb and a folded cloth.***

Chrome surround (Mini and similar): Apply the lashes to the chrome surface next to the headlight glass.

No Chrome surround (New Beetle, PT Cruiser and similar): Apply the lashes to the painted surface just outside any crease around the headlight.

APPLY: Start at one end and curve the base of the lash to follow the edge of the headlight. Make sure to apply enough force to keep bending the lash around the edge of the headlight. Remove the red protective backing bit by bit as you work your way around the headlight.



CLEAN: Make sure the surface is clean and dry before attaching. Use the enclosed Alcohol Prep Pad to remove any dirt, grease, or car wax as your last cleaning step.

Bend the lashes up or down if necessary by bending at the base as shown.

Practice before attaching! The 3M double sided trim tape is VERY STICKY! It cannot be repositioned. Once it touches a surface it is very difficult to remove without messing up the

tape. Once the lash is applied, slide a folded cloth along the length of the lash pressing down firmly with your thumb. Make sure to press rub over every part of the tape.

### **KEEP IN MIND**

1. *Make sure the tips of the lashes are not flexing back and touching the car at high speed. If this is happening, bend the lashes down or trim them shorter with scissors.*
2. *Traveling at excessive speed may cause the lashes to start peeling up. If this happens, remove them immediately and re-apply with fresh 3M tape.*
3. *Best if applied above 50 degrees.*
4. *Avoid application in hot sun.*
5. *Avoid getting wet or driving at high speed for 24 hours after application.*

### **OPTIONAL CRYSTAL EYELINER**

1. Remove a portion of the red protective cover from one end of the Crystal Eyeliner. The crystal eyeliner is long enough for one crystal to overhang the lash at each end. You can trim off crystals to the desired length using scissors.
2. Starting at the outside end of the lash, apply the liner to the edge of the painted surface above the lash or directly on top of the lash if the base is exposed.
3. Work your way along pulling off only a short portion of the protective backing and pressing the crystals down one or two at a time.

NOTE: The 3M tape stretches--do not pull on the strip of crystals as they are applied since this will open up a gap in the spacing between the crystals. Just twist them to bend along the edge of the lash as you press them down in place.

4. Remove the red protective cover bit by bit as you work your way along.



5. If you apply more than one row of crystals you can stretch the tape slightly to align the crystal rows one next to the other as you apply the second row.

*Wash your car before applying if you can!*